


# Joint Base Anacostia - Bolling Snow Removal Map

This map is for reference only. Although every effort has been made to ensure the accuracy of information, errors and conditions originating from physical sources used to develop the database may be reflected on this map. The USN & NAVFAC shall not be liable for any errors, omissions, or damage that results from inappropriate use of this document.

This material is For Official Use Only. Unauthorized reproduction, distribution, publication, or exhibition of this material is STRICTLY PROHIBITED.  
Destroy as "For Official Use Only".



## Legend


- |  |  |   |  |
|--|--|---|--|
|  PRIORITY 1 |  HOUSING PRIORITY 1 |  TENANT/AGENCY SVS |  SNOW DUMP AREA |
|  PRIORITY 2 |  HOUSING PRIORITY 2 |   |  |
|  PRIORITY 3 |  |   |  |
|  PRIORITY 4 |  |   |  |

Naval Facilities Engineering Command  
 NAVFAC Washington GeoReadiness Center  
 (202) 767-0312  
 Map Publication Date: November 2014



Grid: State Plane (Feet), Geographic (Lat/Long)  
 Coordinate System: State Plane Maryland 1900  
 Datum: NAD 1983  
 Map Units: Feet

1:6,000  
 1 inch = 500 feet



This map is for reference only. Although every effort has been made to ensure the accuracy of information, errors and conditions originating from physical sources used to develop the database may be reflected on this map. The USN & NAVFAC shall not be liable for any errors, omissions, or damage that results from inappropriate use of this document.  
 This material is For Official Use Only. Unauthorized reproduction, distribution, publication, or exhibition of this material is STRICTLY PROHIBITED.  
 Destroy as "For Official Use Only".

**FOR OFFICIAL USE ONLY**